



Parts List for 362V Type 10

Item Number	Part Number	Description	Qty Required
1	909832	ARMATURE	1
2	887416	FIELD (360VS 362VS)	1
3	803483	BRUSH CAP	2
4	A22819	SWITCH	1
5	882313	CORD	1
6	873497	BRUSH HOLDER	2
7	N031635	BRUSH & SPRING	2
8	N059515	SWITCH, VS	1
11	803876SV	BEARING	2
12	804211	BEARING,NEEDLE	3
13	803846SV	BEARING	1
14	883202SV	BEARING	1
15	D883500	PINION	1
31	896468	GEAR	1
37	903809	BELT	1
38	903840	DRIVE PULLEY	1
39	904252	DRIVEN PULLEY	1
40	883196	SHAFT DRIVE PULLEY 4	1
41	885104	PULLEY SHAFT 4	1
51	A22833	RH FRAME	1
52	A22835	LH FRAME & COVE	1
53	882859	GEAR HSG COVER	1
54	910499	COVER-BELT	1
57	A23100	HANDLE SET	1
63	698496	PULLEY	1
64	839306	FRAME PROTECTOR BAR	1
65	823466	DRIVE PULLEY	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for 362V Type 10

Item Number	Part Number	Description	Qty Required
84	A03070	SS/A HANDLE SET	1
90	A23158	DUST BAG ASSY	1
100	883485	SCREW	7
101	888117	GASKET	1
102	883782	RUBBER PLUG	1
103	883483	SCREW	2
104	802388	SCREW	2
105	803496	WASHER	2
106	883183	BAFFLE-COOLING SEC	1
107	883182	BAFFLE-COOLING PRIM	1
108	883010	DUST BAFFLE	1
109	875322	SCREW	3
110	886538	SCREW	2
111	879678	SCREW	6
112	892780	SCREW	1
113	883480	SCREW	1
114	694010	SCREW	4
115	882185	SCREW MACHINE STEEL	3
116	883192	GEAR HSG GASLET	1
117	883486	SCREW	4
118	855284	BEARING	3
119	878563	KEY	1
120	801372	NUT	1
121	802942	RING	1
122	801852	SEAL	1
123	803365	CAP	1
124	803341	WASHER	2

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for 362V Type 10

Item Number	Part Number	Description	Qty Required
125	823254	NUT	1
126	A22837	TRACKING BOX	1
127	883479	SCREW	3
129	908909	SHOE ASSY	1
131	852310	SCREW	3
132	887650	YOKE	1
133	698507	CONTROL PLATE	1
134	883477	SCREW	2
135	698511	WEAR PLATE	1
136	698502	LEVER	1
137	848741	WASHER	3
138	874194	SHOULDER SCREW	1
139	858136	NUT	1
140	698504	SPRING	1
141	873946	SPRING	1
142	698500	SPRING	1
143	853455	RING	1
144	803317	WASHER	2
145	873945	SPRING	1
146	878262	SCREW	1
147	A22840	COVER PLATE	1
148	861434	CORD CLAMP	1
150	682063	CONNECTOR VS	1
153	887098	LEAD-ASSY360VS 362VS	1
154	888569	GASKET	1
155	897159	KNOB	1
156	883484	SCREW	2

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for 362V Type 10

Item Number	Part Number	Description	Qty Required
166	894223	SCREW	2
167	896743	COVER	1
174	A11331	WARNING LABEL	1
175	A23710	ID LABEL	1
176	A23322	ID LABEL	1
177	698775	PIN	1
178	A22850	NAMEPLATE	1
179	A23709	WARNING LABEL	1
800	879751	LUBRICANT 4 LBS	1
800	878499	TUBE GREASE	1
861	A02028	CASE-CARRYING	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.