


PORTER-CABLE CORDLESS DRIVER/DRILL

WARNING: Electrical repairs should only be attempted by trained repairmen. Contact the nearest Porter-Cable Service Center or other competent repair center.

878



Parts List for 9878 Type 1

Item Number	Part Number	Description	Qty Required
1	000000-00	No Longer Available	1
1	891238	PINION	1
4	893101	SWITCH	1
53	891239	GEAR BOX/CLUTCH ASSY	1
53	891242	CLUTCH RING	1
57	891321	HANDLE SET	1
83	895507	CHUCK	1
100	894098	SCREW	10
101	897046	SPRING CLIP	2
103	897120	SCREW	10
104	000000-00	No Longer Available	1
105	000000-00	No Longer Available	1
106	891244	SPEED SLECTOR	1
107	888993	SCREW	10
108	891352	RELEASE BUTTON	1
109	891353	SPRING	10
110	892955	CLIP	10
111	000000-00	No Longer Available	1
112	901561	BATTERY TOP	1
113	000000-00	No Longer Available	1
113	8924	UNIVERSAL CHARGER	1
114	000000-00	No Longer Available	1
114	897154	CHARGER	1
114	894366	CIRCUIT BOARD	1
115	000000-00	No Longer Available	1
115	894096	HOUSING SET	1
116	000000-00	No Longer Available	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for 9878 Type 1

Item Number	Part Number	Description	Qty Required
116	000000-00	No Longer Available	1
117	000000-00	No Longer Available	10
117	000000-00	No Longer Available	10
118	000000-00	No Longer Available	1
119	895781	WASHER	10
120	698950	BIT	1
121	000000-00	No Longer Available	1
121	000000-00	No Longer Available	1
122	890390	LATCH	1
122	887712	LATCH CARRYING CASE	1
125	000000-00	No Longer Available	1
125	897154	CHARGER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.