



Parts List for PC13CSL Type 1

Item Number	Part Number	Description	Qty Required
1	5140033-56	SCREW	9
2	5140033-57	SCREW	3
3	5140060-00	COVER	1
4	5140060-01	COVER	1
5	5140033-60	SCREW	2
6	5140033-61	BRUSH HOLDER PLATE	2
7	5140033-62	BRUSH	2
8	5140033-63	BRUSH HOLDER	2
9	5140060-02	MOTOR HOUSING	1
10	5140033-65	SPRING	1
11	5140033-66	WASHER	1
12	5140033-67	BEARING	1
13	5140033-68	DUST SEAL	1
15	5140033-70	BEARING	1
16	5140033-71	RUBBER RING	1
17	5140034-25	FIELD	1
18	5140033-73	PLAIN WASHER	4
19	5140033-74	SPRING WASHER	3
20	5140033-75	SCREW	2
21	5140033-76	SCREW	3
22	5140033-77	SPRING	1
23	5140034-29	WIRE LEAD	2
24	5140033-78	SCREW	5
28	5140033-79	GEAR CASE	1
29	5140033-80	SET SCREW	1
31	5140033-82	LASER	1
32	5140033-83	LENS	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for PC13CSL Type 1

Item Number	Part Number	Description	Qty Required
33	5140033-84	PLAIN WASHER	2
34	5140033-85	SPRING WASHER	2
35	5140033-86	SCREW	2
36	5140033-87	SPRING PIN	1
37	5140033-88	STOPPER	1
38	5140033-89	WIRE CLAMP	1
39	5140033-90	BEARING	1
48	5140033-98	SCREW	3
49	5140033-99	BUSHING	1
50	5140034-00	TORSION SPRING	1
52	5140034-02	CIRCLIP	1
53	5140034-03	LEVER	1
54	5140034-04	SCREW	2
55	5140060-03	UPPER GUARD	1
56	5140060-04	AUXILIARY HANDLE	1
57	5140063-32	CLAMSHELL SET	1
58	5140034-08	TRANSFORMER	1
59	5140034-09	SWITCH	1
60	5140034-10	CONNECTOR	1
61	5140034-11	SPONGE	1
62	5140034-12	CORD PROTECTOR	1
63	5140034-13	CORD CLAMP	1
64	5140034-14	SCREW	2
65	5140060-06	CORDSET	1
66	5140060-07	BUTTON	1
67	5140063-32	CLAMSHELL SET	1
68	5140034-18	E-RING	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenetwork.com for current parts information.

Parts List for PC13CSL Type 1

Item Number	Part Number	Description	Qty Required
69	5140034-19	LEVER	1
70	5140034-20	NUT	1
71	5140034-21	PLAIN WASHER	1
72	5140034-22	WAVE WASHER	1
73	5140034-23	SCREW	1
76	5140034-26	SQUARE BOLT	1
77	5140034-27	NUT	1
78	5140034-28	SCREW	1
80	5140034-30	WING NUT	1
81	5140034-31	PLAIN WASHER	1
82	5140033-95	WING SCREW	1
83	5140033-96	SPRING	1
84	5140034-32	SCREW	1
85	5140034-33	INDICATOR	1
86	5140033-97	RIP FENCE	1
87	5140034-34	INNER FLANGE	1
88	77-737	7 1/4IN 24T PIR CARB BLD	1
89	5140034-36	CLAMP	1
90	5140058-26	BLADE BOLT	1
90	5140034-37	BLADE BOLT	1
92	5140034-39	WRENCH	1
93	5140034-97	LEAD WIRE	2
94	5140034-98	LEAD WIRE	2
95	90538002	NAMEPLATE	1
96	90538456	WARNING LABEL	1
97	90538399	LASER LABEL	1
98	90538872	WARNING LABEL	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenetwork.com for current parts information.

Parts List for PC13CSL Type 1

Item Number	Part Number	Description	Qty Required
99	90538873	WARNING LABEL	1
223	5140031-90	GEAR ASSY	1
224	5140031-91	LOWER GUARD ASSY	1
225	5140031-92	BASE PLATE	1
226	5140031-93	ARMATURE & BRGS	1
227	5140031-94	LASER ASSEMBLY	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.