



Parts List for PC650HD Type 1

Item Number	Part Number	Description	Qty Required
1	621050-00	1/2 CHUCK	1
2	621400-00	CHUCK KEY	1
3	90537594	HOUSING ASSY.	1
4	90538471SV	GEAR CASE ASSY	1
5	90538247SV	SPINDLE	1
6	639074-00	KNOB	1
7	639073-00SV	PLATE	1
8	90538160SV	BEARING HOUSING	1
9	637916-04	BRUSH	2
9	90540127	BRUSH RING ASY	1
12	000000-00	No Longer Available	1
13	629167-00	COIL SPRING	1
14	90537743	REVERSE LEVER	1
15	633510-00	BAR,PIVOT	1
16	90536723-06	CORDSET	1
17	329301-00	CLAMP,CORD	1
18	330005-01	PROTECTOR,CORD	1
19	605256-01	SCREW	1
20	330019-03	SCREW	7
21	330019-63	SCREW	2
22	330019-08	SCREW	4
23	330019-05	SCREW,PLASTITE	1
24	330019-02	SCREW,PLASTITE	2
25	90537809	NAMEPLATE	1
27	635900-02	LABEL	1
28	639090-02	LABEL	1
29	493312-00	WARN LABEL	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for PC650HD Type 1

Item Number	Part Number	Description	Qty Required
31	90538129	SIDE HANDLE ASY	1
32	372814-00	DEPTH STOP	1
33	606290-01	BEARING	1
34	622172-00	RATCHET	1
35	629149-00	SPRING	1
36	90538196	CHUCK KEY HOLDER	1
46	635176-00	BEARING SLEEVE	1
800	286436-00	GREASE	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.