



Parts List for PC650HD Type 2

Item Number	Part Number	Description	Qty Required
1	5140071-68	CHUCK & KEY	1
2	330034-08	KEY,CHUCK	1
3	90548412	CLAMSHELL SET	1
4	90538471SV	GEAR CASE ASSY	1
5	90538247SV	SPINDLE	1
6	639074-00	KNOB	1
7	639073-00SV	PLATE	1
8	90538160SV	BEARING HOUSING	1
9	637916-04	BRUSH	2
9	90540127	BRUSH RING ASY	1
12	90544100	SWITCH	1
13	629167-00	COIL SPRING	1
14	90548441	REVERSE LEVER	1
16	90536723-06	CORDSET	1
17	329301-00	CLAMP,CORD	1
18	330005-01	PROTECTOR,CORD	1
19	605256-01	SCREW	1
20	330019-03	SCREW	7
21	330019-63	SCREW	2
22	330019-08	SCREW	2
23	330019-05	SCREW,PLASTITE	1
24	330019-02	SCREW,PLASTITE	2
25	90549552	NAMEPLATE	1
31	90538129	SIDE HANDLE ASY	1
32	580787-00	DEPTH STOP	1
33	574853-08	BEARING	1
34	622172-00	RATCHET	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for PC650HD Type 2

Item Number	Part Number	Description	Qty Required
35	629149-00	SPRING	1
36	90538196	CHUCK KEY HOLDER	1
37	330019-07	SCREW,THD.FORM	2
800	286436-00	GREASE	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenetwork.com for current parts information.