



Parts List for PCB220TS Type 1

Item Number	Part Number	Description	Qty Required
1	5140082-00	CORD CLAMP	1
2	5140082-01	COMPRESSION SPRING	1
3	5140082-02	STRAP	1
4	5140082-03	ANCHOR BLOCK	1
5	5140082-04	SETTING NUT	1
6	5140082-05	ARBOR COLLAR	1
7	5140082-06	SUPPORT PLATE	1
8	5140082-07	LOCATING RING	1
9	5140082-08	LOCATION SEAT	2
10	5140082-09	BEVEL GEAR	2
11	5140082-10	PIVOT SUPPORT	2
12	5140082-11	HEX WRENCH	1
13	5140082-12	FLAT WASHER	4
14	5140078-51	FLAT WASHER	1
15	5140079-43	FLAT WASHER	1
16	5140082-13	FLAT WASHER	1
17	5140082-14	FLAT WASHER	1
18	5140082-15	FLAT WASHER	2
19	5140082-16	FLAT WASHER	1
20	5140082-17	FLAT WASHER	1
21	5140082-18	FLAT WASHER	4
22	5140082-19	FLAT WASHER	4
23	5140082-20	FLAT WASHER	1
24	5140082-21	FLAT WASHER	2
25	5140082-22	SPRING WASHER	4
26	5140082-23	SPRING WASHER	1
27	5140078-54	LOCK WASHER	2

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for PCB220TS Type 1

Item Number	Part Number	Description	Qty Required
28	283716-00	WASHER,LOCK	1
29	5140082-24	SPRING PIN	3
30	5140082-25	C-RING	1
31	5140082-26	C-RING	1
32	5140082-27	HEX SOC HD SCR	2
33	5140078-65	HEX SOC HD SCR	4
34	5140082-28	PAN HEAD SCREW	1
35	5140082-29	PAN HEAD SCREW	1
36	5140082-30	TRUSS HEAD SCREW	1
37	5140078-67	SCREW	1
38	5140082-31	TRUSS HEAD SCREW	1
39	5140082-32	TRUSS HEAD SCREW	2
40	5140077-69	SCREW	2
41	5140082-33	SELF TAPPING SCREW	4
42	5140082-34	SELF TAPPING SCREW	4
43	5140082-35	SELF TAPPING SCREW	4
44	5140082-36	SELF TAPPING SCREW	2
45	5140082-37	SELF TAPPING SCREW	2
46	5140082-38	SELF TAPPING SCREW	2
47	5140082-39	SELF TAPPING SCREW	1
48	5140082-40	SELF TAPPING SCREW	5
49	5140082-41	SELF TAPPING SCREW	2
50	5140082-42	SELF TAPPING SCREW	6
51	5140082-43	SELF TAPPING SCREW	4
52	5140082-44	SELF TAPPING SCREW	2
53	5140077-72	SCREW	1
54	5140077-73	SCREW	2

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for PCB220TS Type 1

Item Number	Part Number	Description	Qty Required
55	5140082-45	PAN HEAD SCREW	1
56	5140082-46	BOLT	2
57	5140082-47	BOLT	1
58	5140082-48	HEX NUT	4
59	5140082-49	NUT	2
60	5140078-78	LOCK NUT	5
61	284867-00	CHUCK,NUT	8
62	5140078-79	LOCK NUT	9
63	5140082-50	NUT & WASHER	2
64	5140082-51	STRAIN RELIEF	1
65	5140082-52	STRAIN RELIEF	3
66	5140082-53	CABLE CLAMP	1
67	5140082-54	LEADWIRE ASSY.	1
68	5140082-55	CIRCUIT BRKR/SWITCH	1
69	5140082-56	SLIDE ASSY.	1
70	5140082-57	SLIDE ASSY.	1
71	5140082-58	RUBBER PAD	1
72	5140082-59	SET PLATE	2
73	5140082-60	LOCATING BAR	1
74	5140082-61	ROLL PIN	1
75	5140082-62	ANCHOR PLATE	2
76	5140082-63	LOCATING BAR	1
77	5140082-64	BUSH	1
78	5140082-65	PARALLEL PIN	2
79	5140082-66	HEX BOLT	2
80	5140082-67	BRACKET STOP	1
81	5140082-68	SPACER	4

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for PCB220TS Type 1

Item Number	Part Number	Description	Qty Required
82	5140082-69	SCREW W/WASHER	1
83	5140082-70	FOLLOWER PLATE	1
84	5140082-71	SCREW W/WASHER	4
85	5140082-72	HEX SCREW	1
86	5140082-73	CORD CLAMP	2
87	5140082-74	EXT. TUBE	2
88	5140082-75	LOCATION SEAT	2
89	5140082-76	LOCATION SEAT	1
90	5140082-77	COVER	1
91	5140082-78	RACK	1
92	5140082-79	NEEDLE POINTER	1
93	5140082-80	TILT POINTER	1
94	5140082-81	KNOB	1
95	5140082-82	PUSH STICK	1
96	5140082-83	CUSHION	1
97	5140082-84	HANDLE	1
98	5140082-85	LOCATING BAR	1
99	5140082-86	HANDLE	1
100	5140082-87	ANGLE ADJ. ASSY.	1
101	5140082-88	SOCKET HEAD SCREW	6
102	5140082-89	RACK	1
103	5140082-90	SOCKET HEAD BOLT	2
104	5140082-91	SELF TAPPING SCREW	6
105	5140082-92	SOCKET HEAD SCREW	3
106	5140082-93	DUST GUARD	1
107	5140097-90	DADO THROAT PLATE	1
107	5140082-94	INSERT	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for PCB220TS Type 1

Item Number	Part Number	Description	Qty Required
108	5140082-95	SPACER	2
109	5140082-96	PAWL ASSY.	1
110	5140082-97	FLAT WASHER	2
111	5140082-98	POINTER BRACKET	1
112	5140082-99	BLADE GUARD ASSY	1
113	5140083-00	SPACER	1
114	5140083-01	BLADE GUARD RIGHT	1
115	5140083-02	BLADE GUARD LEFT	1
116	5140083-03	REAR EXTENSION WING	1
117	5140083-04	REAR SIDE COVER	2
118	5140083-05	FRONT SIDE COVER	2
120	5140083-07	FRONT RAIL	1
121	5140083-08	REAR RAIL	1
122	5140083-09	RETAINING CLIP	1
123	5140083-10	BODY	1
124	5140083-11	DUST COLLECTOR	1
125	5140083-12	BRACKET,CLAMP	1
126	5140083-13	ANCHOR BLOCK	1
127	5140083-14	HEIGHT WORM	1
128	5140083-15	CLAMP BAR	1
129	5140083-16	CLAMP	1
130	5140083-17	HEIGHT ADJUST BOLT	1
131	5140083-18	RIVING KNIFE	1
132	5140083-19	MOTOR ASSY.	1
133	5140083-20	SWITCH KEY	1
134	5140078-14	ROCKER SWITCH	1
135	5140078-14	ROCKER SWITCH	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for PCB220TS Type 1

Item Number	Part Number	Description	Qty Required
136	5140083-22	SWITCH BOX	1
137	5140083-23	RIP FENCE ASSY	1
138	5140083-24	HAND WHEEL ASSY.	1
139	5140083-25	HAND WHEEL ASSY.	1
140	5140083-26	BODY SHELL	1
141	5140083-27	MITER GAUGE ASSY	1
142	5140083-28	SWITCH BOX ASSY	1
143	5140083-29	LOCK HANDLE ASSY	1
144	5140083-30	HEX WRENCH	1
145	5140083-31	WRENCH	1
146	5140083-32	POWER CABLE	1
147	5140083-33	SOCKET HEAD BOLT	1
148	5140083-34	TABLE	1
149	5140083-35	EXTENSION TABLE	1
150	5140083-36	LABEL	1
151	5140083-37	LABEL	1
152	5140083-38	WARNING LABEL	1
153	5140083-39	STICKER	1
154	5140083-40	LABEL	1
155	5140083-41	SCALE	1
156	5140083-42	POWER CABLE ASSY.	1
157	5140083-43	WARNING LABEL	1
158	5140083-44	BLADE	1
159	5140083-45	PLUNGER HSG. ASSY.	1
160	5140083-46	SCALE ASSY.	1
161	5140083-47	LEAD WIRE ASSY	1
162	5140096-02	HANDLE	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for PCB220TS Type 1

Item Number	Part Number	Description	Qty Required
200	5140083-48	KNOB	1
201	5140083-49	BOLT	3
202	5140083-50	PLUNGER HSG.	1
203	5140083-51	FLAT WASHER	2
204	5140083-52	FLAT WASHER	4
205	5140078-56	WAVY WASHER	1
207	5140079-44	HEX HEAD BOLT	4
208	5140078-60	HEX HEAD BOLT	4
209	5140083-54	HEX HD BOLT	3
210	5140083-55	SCREW	1
211	285304-00	SCREW	4
215	5140083-57	NUT	2
216	5140083-58	HEX HEAD BOLT	1
217	5140083-59	HEX HEAD BOLT	2
218	5140083-60	BOLT	2
219	5140083-61	FLAT WASHER	1
220	5140083-62	SOCKET HEAD SCREW	1
221	5140083-63	END CAP	1
222	5140083-64	CASTER	2
223	5140083-65	WING NUT	1
224	5140083-66	LEVELING PAD	1
225	5140083-67	SCREW	2
226	5140083-68	FLAT WASHER	4
227	5140083-69	SELF TAPPING SCREW	4
228	5140083-70	SUPPORT ASSY.	1
229	5140083-71	SUPPORT ASSY.	1
230	5140083-72	CONNECTOR TUBE	2

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for PCB220TS Type 1

Item Number	Part Number	Description	Qty Required
231	5140083-73	SUPPORT ASSY.	1
232	5140083-74	ANCHOR PLATE	1
233	5140083-75	MITER BAR	2
234	5140083-76	PLUNGER HANDLE	2
235	5140083-77	STOPPER	2
236	5140083-78	BUSH	2
237	5140083-79	SLEEVE	2
238	5140083-80	HINGE	1
239	5140083-81	ADJUSTABLE TUBE	1
240	5140083-82	HANDLE	1
241	5140083-83	COMPRESSION SPRING	4
242	5140083-84	SLEEVE	2
243	5140083-85	END CAP	4
244	5140083-86	PLATE	1
245	5140083-87	SET PLATE	1
246	5140083-88	RETAINING CLIP	1
247	5140083-89	SLEEVE	2
248	5140083-90	WARNING LABEL	1
249	5140083-91	WARNING LABEL	1
250	5140083-92	ANCHOR PLATE	1
251	5140083-93	SUPPORT TUBE	1
252	5140083-94	END CAP	1
253	5140083-99	BOLT	2
300	5140084-00	BALL BEARING	1
301	5140084-01	NEEDLE BEARING	1
302	5140084-02	C-RING	1
303	5140084-03	PARALLEL KEY	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenetwork.com for current parts information.

Parts List for PCB220TS Type 1

Item Number	Part Number	Description	Qty Required
304	5140084-04	HEX SOC HD SCR	2
306	5140084-06	BRUSH HLDR ASSY	2
307	5140084-07	BRUSH ASSY.	2
308	5140084-08	BRUSH COVER	2
309	5140084-09	SELF TAPPING SCREW	2
310	5140084-10	PAN HEAD SCREW	4
311	5140084-11	WAVE WASHER	1
312	5140084-12	FLOW GUIDE	1
313	5140084-13	MOTOR COVER	1
314	5140084-14	SPACER	1
315	5140084-15	GEAR	1
316	5140084-16	CUTTER SHAFT ASSY	1
317	5140084-17	BEARING COVER	1
318	5140084-18	BEARING SEAT	1
319	5140084-19	ARMATURE ASSY.	1
320	5140084-20	SCREW	2
321	5140084-21	LABEL	1
322	5140084-22	BRACKET	1
324	5140084-24	FIELD ASSY.	1
846	5140083-97	HARDWARE BAG	1
846	5140083-98	HARDWARE BAG	1
846	5140083-95	HARDWARE BAG	1
846	5140083-96	HARDWARE BAG	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenetwork.com for current parts information.