



## Parts List for PCB270TS Type 1

Item Number	Part Number	Description	Qty Required
1	5140084-25	WHEEL	1
2	5140084-26	COMPRESSION SPRING	1
3	5140084-27	HANDLE	1
4	5140084-28	WRENCH	1
5	5140084-29	BEVEL GEAR	1
6	5140082-04	SETTING NUT	1
7	5140082-05	ARBOR COLLAR	1
8	5140082-09	BEVEL GEAR	1
9	5140084-30	BALL BEARING	3
10	5140084-31	HEX WRENCH	1
11	5140082-12	FLAT WASHER	2
12	5140083-51	FLAT WASHER	4
13	5140078-52	FLAT WASHER	1
14	5140083-52	FLAT WASHER	4
15	5140082-14	FLAT WASHER	1
16	5140082-18	FLAT WASHER	4
17	5140084-32	FLAT WASHER	2
18	5140084-33	FLAT WASHER	1
19	5140084-34	FLAT WASHER	1
20	5140084-35	FLAT WASHER	1
21	5140084-36	SPRING WASHER	4
22	283716-00	WASHER,LOCK	5
23	5140084-37	WAVE WASHER	2
24	5140084-38	SPRING PIN	5
25	5140084-39	PARALLEL KEY	2
26	5140084-40	HEX HD BOLT	6
27	5140084-41	HEX HD BOLT	4

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.

## Parts List for PCB270TS Type 1

Item Number	Part Number	Description	Qty Required
28	5140078-60	HEX HEAD BOLT	6
29	5140082-27	HEX SOC HD SCR	9
30	5140084-42	HEX SOC HD SCR	6
31	5140084-43	HEX HD SCREW	6
32	5140084-44	HEX SOC HD SCR	4
33	5140084-45	HEX SOC HD SCR	4
34	5140082-30	TRUSS HEAD SCREW	1
35	5140084-46	SCREW	2
36	5140084-47	SCREW	4
37	5140084-48	SCREW	6
38	5140078-71	SCREW	10
39	5140077-69	SCREW	2
40	5140077-70	SCREW	1
41	5140084-49	SELF TAPPING SCREW	1
42	5140084-50	SELF TAPPING SCREW	2
43	5140084-51	SELF TAPPING SCREW	4
44	5140084-52	SELF TAPPING SCREW	7
45	5140082-40	SELF TAPPING SCREW	7
46	5140084-54	PAN HEAD SCREW	4
47	5140084-55	PAN HEAD SCREW	2
48	5140084-56	PAN HEAD SCREW	2
49	5140082-48	HEX NUT	3
50	5140084-57	HEX NUT	2
51	5140077-78	HEX NUT	3
52	5140084-58	HEX NUT	1
53	5140084-59	HEX NUT	2
54	5140084-60	CROWN NUT	2

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenetwork.com](http://www.dewaltservicenetwork.com) for current parts information.

## Parts List for PCB270TS Type 1

Item Number	Part Number	Description	Qty Required
55	5140084-61	SQUARE NUT	6
56	5140078-78	LOCK NUT	3
57	284867-00	CHUCK,NUT	3
58	5140079-46	FLANGED HEX NUT	26
59	5140084-62	STRAIN RELIEF	1
60	5140084-63	STRAIN RELIEF	5
61	5140084-64	CABLE TIE	1
62	5140084-65	COMPRESSION SPRING	1
63	5140084-66	COLLAR	1
64	5140084-67	COPPER BUSHING	4
65	5140084-68	SPRING PIN	2
66	5140084-69	O-RING ROD	2
67	5140084-70	SCREW W/WASHER	10
68	5140084-71	PARALLEL PIN	1
69	5140084-72	SLEEVE	1
70	5140084-73	BEVEL GEAR	1
71	5140084-74	REINFORCE PLATE	1
72	5140084-75	SET PLATE	2
73	5140084-76	DUST GUARD	1
74	5140084-77	GUIDE BLOCK	1
75	5140084-78	SPONGE	2
76	5140084-79	WHEEL	1
77	5140084-80	SET PLATE	1
78	5140084-81	LOCATION SEAT	2
79	5140084-82	ARM BRACKET	2
80	5140084-83	POINTER	1
81	5140084-84	ROLLING WHEEL	2

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.

## Parts List for PCB270TS Type 1

Item Number	Part Number	Description	Qty Required
82	5140084-85	LINKAGE PLATE	1
83	5140084-86	LEFT SIDE COVER	1
84	5140084-87	RIGHT SIDE COVER	1
85	5140084-88	SCREW	2
86	5140084-89	HEX SOC HD SCR	4
87	5140084-90	HEX NUT	1
88	5140084-91	BALL BEARING	2
89	5140084-92	HEX SOC HD SCR	4
90	5140084-93	WASHER	1
91	5140084-94	MOUNTING SWITCH	1
92	5140084-95	SWITCH BOX	1
93	5140084-96	COMPRESSION SPRING	1
94	5140084-97	WIRE CONNECTOR	1
95	5140084-98	WIRE CONNECTOR	1
96	5140084-99	LEAD WIRE ASSY	1
97	5140085-00	LEAD WIRE ASSY	1
98	5140085-01	LEAD WIRE ASSY	1
99	5140085-02	WORM	1
100	5140085-03	BEVEL GEAR	2
101	5140085-04	SWITCH BOX COVER	1
102	5140085-05	ANCHOR BLOCK	2
103	5140085-06	SELF TAPPING SCREW	2
104	5140082-82	PUSH STICK	1
105	5140085-09	CIRCUIT BREAKER	1
106	5140085-10	DUST GUARD	1
107	5140085-11	SELF TAPPING SCREW	24
108	5140085-12	HEX SOC HD SCR	2

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.

## Parts List for PCB270TS Type 1

Item Number	Part Number	Description	Qty Required
109	5140082-99	BLADE GUARD ASSY	1
110	5140083-00	SPACER	1
111	5140083-01	BLADE GUARD RIGHT	1
112	5140085-13	CONNECTOR BOX	1
113	5140085-14	CONNECTOR BOX COVER	1
114	5140085-15	BODY SHELL RIGHT	1
115	5140085-16	BODY SHELL LEFT	1
116	5140085-17	BODY SHELL FRONT	1
117	5140085-18	EXTENSION WING	2
118	5140085-19	REAR BRACKET	2
119	5140085-20	TABLE	1
120	5140085-21	TABLE SUPPORT	1
121	5140085-22	LEFT REAR RAIL	1
122	5140085-23	RIGHT REAR RAIL	1
123	5140085-24	BODY	1
124	5140085-25	RACK	2
125	5140085-26	CLAMP BAR	1
126	5140085-27	HEIGHT LEVER SEAT	1
127	5140085-28	RIVING KNIFE	1
128	5140085-29	DUST COLLECTOR	1
129	5140085-30	SET PLATE	1
130	5140085-31	DUST COLLECTOR JOINT	1
131	5140085-32	ELEVATING SHAFT	1
132	5140085-33	CENTER SHAFT	1
133	5140085-34	CENTER SHAFT	1
134	5140085-35	SET BOLT	6
135	5140085-36	HEIGHT ADJUST BOLT	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.

## Parts List for PCB270TS Type 1

Item Number	Part Number	Description	Qty Required
136	5140085-37	LOCKING ROD	1
137	5140085-38	LEFT RAIL	1
138	5140085-39	RIGHT RAIL	1
139	5140085-40	MOTOR PULLEY	1
140	5140085-41	PULLEY	1
141	5140085-42	CUTTER SHAFT	1
142	5140085-43	HANDLE ASSEMBLY	1
143	5140085-44	KNOB ASSEMBLY	1
144	5140085-45	BODY SHELL	1
145	5140085-46	SET PLATE	1
146	5140085-47	SET PLATE	1
147	5140085-48	MOTOR ASSY	1
148	5140085-49	PAWL ASSY.	1
149	5140085-50	MITER GAGE ASSY.	1
150	5140085-51	RIP FENCE ASSY	1
151	5140085-52	CLAMP BAR	1
152	5140085-53	LOCK HANDLE	1
153	5140085-54	SPECIAL NUT	1
154	5140085-55	DRIVE BELT	1
155	5140085-56	PUSH IN PIN	2
156	5140085-57	RUBBER SLEEVE	1
157	5140078-14	ROCKER SWITCH	1
158	5140085-58	SPACER	1
159	5140085-59	LEAD WIRE ASSY	1
160	5140085-60	POWER CABLE	1
161	5140085-61	CAUTION LABEL	1
162	5140085-62	CAUTION LABEL	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.

## Parts List for PCB270TS Type 1

Item Number	Part Number	Description	Qty Required
163	5140085-63	LEFT SCALE	1
164	5140085-64	RIGHT SCALE	1
165	5140085-65	CAUTION LABEL	1
166	5140085-66	LABEL	1
167	5140085-67	CAUTION LABEL	1
168	5140085-69	COLLAR	1
169	5140083-43	WARNING LABEL	1
170	5140085-70	BRAND LABEL	1
171	5140083-44	BLADE	1
172	5140085-71	HEX.SOC.HD.BOLT	4
173	5140085-72	BUSH	2
174	5140085-76	HANDLE ASSY.	1
175	5140085-77	PLUNGER HSG. ASSY.	1
176	5140085-78	COVER	1
177	5140085-79	TILTING SCALE	1
178	5140097-89	THROAT PLATE	1
178	5140081-99	THROAT PLTE ASM	1
200	5140085-80	LEVELING PAD	1
201	5140085-81	CORD CLAMP	2
204	5140085-83	SCREW W/WASHER	2
205	5140079-45	CARRIAGE BOLT	22
207	5140085-84	HEX NUT	1
209	5140085-85	HEX NUT	4
210	5140085-86	ADJUSTABLE FOOT	1
211	5140085-87	CUSHION	3
212	5140085-88	HOOK	1
213	5140083-85	END CAP	2

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenetwork.com](http://www.dewaltservicenetwork.com) for current parts information.



## Parts List for PCB270TS Type 1

Item Number	Part Number	Description	Qty Required
214	5140085-90	CASTER	2
215	5140085-91	BRACKET TRAY ASSY.	1
216	5140085-92	PEDAL ASSY.	1
217	5140085-93	RETAINING CLIP	2
218	5140085-94	CASTER	2
219	5140085-95	HEX HEAD BOLT	2
220	5140085-96	HEX HEAD BOLT	1
221	5140085-97	CAUTION LABEL	1
222	5140086-03	CONNECTOR ASSY	1
223	5140086-05	RIGHT LEG SUPPORT	1
224	5140086-06	RIGHT FRONT LEG	1
225	5140086-07	REAR RIGHT LEG	1
226	5140086-08	LEFT LEG SUPPORT	1
227	5140086-09	FRONT LEFT LEG	1
228	5140086-10	REAR LEFT LEG	1
229	5140086-11	FRONT LEG SUPPORT	1
230	5140086-12	REAR TOP LEG SUPPORT	1
231	5140086-13	REAR BOTTOM LEG SUPP	1
232	5140086-14	HEX HEAD BOLT	2
300	5140086-15	PAN HEAD SCREW	2
301	5140086-16	LEAD WIRE ASSY	1
302	5140086-17	BALL BEARING	1
305	5140086-19	WAVE WASHER	1
306	5140086-20	PAN HEAD SCREW	2
307	5140086-21	FLANGE NUT	4
308	5140086-22	STRAIN RELIEF	2
309	5140086-23	CONTACT PLATE	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.

## Parts List for PCB270TS Type 1

Item Number	Part Number	Description	Qty Required
310	5140086-24	CENTRIFUGAL STARTER	1
311	5140086-25	CAPACITOR	1
312	5140086-26	FAN	1
313	5140086-27	COVER	1
314	5140086-28	CAPACITOR COVER	1
315	5140086-29	CAPACITOR	1
316	5140086-30	CAPACITOR COVER	1
317	5140086-31	CAPACITOR COVER	2
318	5140086-32	CAPACITOR COVER	2
319	5140086-33	INSULATE PLATE	1
320	5140086-34	SCREW W/WASHER	4
321	5140086-35	ARMATURE ASSY.	1
322	5140086-36	REAR MOTOR COVER	1
323	5140086-37	FRONT HOUSING	1
325	5140086-39	MOTOR HOUSING ASSY.	1
326	5140086-40	FIELD ASSY.	1
327	5140086-41	SPRING PIN	1
328	5140086-42	PAN HEAD SCREW	4
329	5140086-43	SCREW W/WASHER	6
330	5140086-44	PAN HEAD SCREW	1
331	5140086-45	TERMINAL	2
846	5140086-00	HARDWARE BAG	1
846	5140085-99	HARDWARE BAG	1
846	5140085-98	HARDWARE BAG	1
846	5140086-04	HARDWARE BAG	1
846	5140086-02	HARDWARE BAG	1
846	5140086-01	HARDWARE BAG	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.

## Parts List for PCB270TS Type 1

Item Number	Part Number	Description	Qty Required
846	5140085-68	HARDWARE BAG	1
846	5140085-08	HARDWARE BAG	1
846	5140085-07	HARDWARE BAG	1
846	5140085-75	HARDWARE BAG	1
846	5140085-74	HARDWARE BAG	1
846	5140085-73	HARDWARE BAG	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.