





**RK4114K**

**Version:00  
Date:060815**

NO.	Part Number	Part Description	Quantity
1	2PPS02C0003000A0	Top cover	1
2	200W4000007000A0	Screw	4
3	2PPS02A0013002A0	Up/Down cover	1
5	200T0030024001A0	Brush	2
6	200W4100004000A0	Screw	6
7	200T0065002000A0	Cord protector	1
<b>101</b>	<b>2PPS02A0P01000A0</b>	<b>Brush holder Set</b>	<b>2</b>
4	200T0050003000A0	Brush spring	2
8	200T0040037000A0	Brush holder	2
9	200W4000020001A0	Screw	2
10	2PPS02A0006000A0	Switch cover	1
11	200W0020089001A0	Switch	1
13	200T0200005000A0	Cord clamp	1
15	2PPS02A0601002A0	Cord & plug	1
59	200T0150004000A0	Terminal	4
19	2PPS02BPK21002A0	Rated label	1
20	2PPS02BPK20002A0	Brand label	1
21	2PPS02A0101002A0	Housing	1
22	2PPS02A0007000A0	Clasp	4
26	2PPS02A0011000A0	Dust catcher	1
31	200W4000003000A0	Screw	2
32	2PPS02A0304000A0	Kentledge	2
33	2PPS02A03028A1A0	Soleplate	1
34	2PPS02A0P03100A0	Steel wire nip	1
<b>103</b>	<b>2PPS02A0P02100A0</b>	<b>Foamy board Set</b>	<b>1</b>
36	200W4000033000A0	Screw	4
37	200T0070005000A0	Seal sheath	1
<b>102</b>	<b>2PPS02A0A02200A0</b>	<b>Rotor set</b>	<b>1</b>
38	200W8000007000A0	Bearing	1
39	200T0020005000A0	Dustproof ring	1
43	20TA9510015000AA	Rotor	1
40	20TA9500018000A0	Stator	1
41	200W4000049000A0	Screw	2
42	2PPS02A0009000A0	Shock absorption	4
45	2PPS02A0111000A0	Middle cover	1
46	200W8000015000A0	Bearing	1
47	200T0240004000A0	Gasket	2
48	2PPS02B0223000A0	Fan	1
49	2PPS02A0008000A0	Wind baffle	1
50	200W4000096000A0	Screw	2

52	200W8000037000A0	Bearing	1
53	200W1150001001A0	Paper punch	1
<b>105</b>	<b>2PPS02A0400001A0</b>	<b>Dust bag Set</b>	<b>1</b>
57	200T0280108000A0	Inner wiring	2
58	200T0280113000A0	Inner wiring	1
61	2PPS02A0301000A0	Airproof loop	1
63	2PPS02A0014000A0	Washer	1
64	200W4000091000A0	Self tapping screw	1
65	200W4000040000A0	Screw	2
66	2PFS01A0F01000A0	Connector	1