

Item	Part Number	Description	Quantity
2	1 619 P08 102	Field 115V	1
3	1 619 P08 002	Armature 115V	1
4	1 619 X08 653	Switch	1
5	1 619 X08 584	Power supply cord	1
6	1 619 X08 308	Grommet	1
7	1 619 X04 671	Cable Clip	1
9	1 619 X09 203	Sticker	1
13	2 610 024 748	Ball Bearing	1
14	1 619 X04 676	Ball Bearing	1
16	1 619 X04 708	Brush Holder	2
20	1 619 X04 679	Warning Plate	1
22	1 619 X09 219	Hood	1
23	1 619 X01 249	Washer	1
24	1 619 X04 683	Washer	1
25	1 619 X04 684	Oil Drain Plug	1
25/4	1 616 B10 364	O-Ring	1
26	1 619 X03 643	Collar bolt	1
27	1 619 X01 262	Stud	1
28	1 619 X04 693	Lower guard	1
29	1 619 X04 709	Set Of Handles	1
31	2 610 017 875	Ball Bearing	1
32	2 610 901 971	Screw	1
33	1 619 X04 765	Extension Spring	1
35	2 610 319 494	End stop	1
36	2 610 341 359	Spring retaining ring	1
37	1 619 X07 782	Insulating Tube	1
38	1 619 X09 205	Upper guard	1
39	1 619 X07 688	Lever	1
40	1 619 X04 707	Handle	1
42	1 619 X01 253	Bearing Plate	1
43	1 619 X01 255	Guard Plate	1
45	1 619 X04 783	Cover	1
46	1 619 X01 268	Device cap	2

Item	Part Number	Description	Quantity
47	1 619 X04 712	O-Ring	1
48	1 619 X04 780	Collar	1
51	2 610 004 341	Washer	1
52	2 610 912 616	Washer	2
53	2 610 968 747	Spring retaining ring	2
54	1 619 X04 719	Locking Lever	2
55	2 610 017 348	groove ball bearing	1
56	2 610 027 039	Set screw	2
57	2 610 315 299	Screw	2
58	2 610 315 380	Screw	4
59	1 619 X03 644	Screw	1
60	1 619 X06 222	O-Ring	1
62	1 619 X07 724	Washer	1
63	2 610 329 955	Screw	3
64	1 619 X01 786	Contact Screw	4
65	2 610 306 355	Washer	3
66	1 619 X01 263	Stud	1
67	1 619 X04 687	O-Ring	1
68	2 610 932 332	Screw	3
69	2 610 932 460	Self-locking nut	1
71	2 610 027 002	Screw	5
72	2 610 911 837	Bolt	1
73	2 610 004 459	Spring Washer	2
74	1 619 X01 257	Rubber Gasket	1
75	1 619 X07 731	Seal	1
78	1 619 X04 740	Seal	1
79	1 619 X04 738	Screw	4
80	1 619 X06 749	Screw	1
81	1 619 X04 754	Screw	2
82	1 619 X01 258	mat seal	1
83	1 619 X05 847	Washer	1
84	2 610 318 324	Nut	1
85	1 619 X06 294	Screw	1
86	1 619 X04 746	Screw	4
87	1 619 X06 242	Bushing	1
88	1 619 X06 254	Washer	1
90	1 619 X05 948	Bearing Cover	1
91	1 619 X06 749	Screw	4
92	2 610 932 218	Screw	1
93	1 619 X01 283	Nut	2
107	2 610 911 889	Set screw	1
310	1 619 X04 768	Set screw	1
320	1 619 X04 669	Spring	1
651	1 619 X04 755	Wrench Socket	1
801	1 619 X09 235	Motor Housing	1

