



Model BJR181Z Parts List

Fig. No.	Part No.	Description	Q'ty	Unit
1	163453-5	SHOE	1	PC.
2	421945-3	INSULATION COVER	1	
3	421894-4	PROTECTOR	1	PC.
4	961078-7	RETAINING RING (EXT) S-18	1	PC.
5	310160-3	DRIVING SLEEVE	1	PC.
6	256492-3	SHOULDER PIN 5	1	PC.
7	233345-3	COMPRESSION SPRING 6	1	PC.
8	268094-3	PIN 3	1	PC.
9	331639-1	GUIDE SLEEVE	1	PC.
10	256158-5	PIN 3	1	PC.
11	417791-0	DRIVING SLEEVE GUIDE	1	PC.
12	418311-3	SLEEVE	1	PC.
13	345214-7	PUSH PLATE	1	PC.
14	233025-1	COMPRESSION SPRING 2	1	PC.
15	231687-9	TORSION SPRING 17	1	PC.
16	213151-2	OIL SEAL 14	1	PC.
17	213174-0	X RING 14	1	PC.
18	154813-2	GEAR HOUSING COVER COMPLETE	1	
	D10	INC. 16,17		
19	418806-6	CAP	1	PC.
20	631689-9	LED CIRCUIT	1	
21	911243-8	PAN HEAD SCREW M5X25	4	PC.
22	232221-8	LEAF SPRING A	1	PC.
23	162236-0	SHIFT BUTTON	1	PC.
24	421946-1	SEAL RING	1	
25	345480-6	SLIDE PLATE	1	PC.
26	214170-1	PLANE BEARING 14A	1	PC.
27	341462-6	PLATE	1	PC.
28	911225-0	PAN HEAD SCREW M5X16	2	PC.
29	154788-5	SLIDER COMPLETE	1	PC.
30	214170-1	PLANE BEARING 14A	1	PC.
31	341462-6	PLATE	1	PC.
32	911225-0	PAN HEAD SCREW M5X16	2	PC.
33	265148-7	TORX SOCKET HEAD SCREW M5X14	2	PC.
34	344795-8	PLATE C	1	PC.
35	265148-7	TORX SOCKET HEAD SCREW M5X14	2	PC.
36	344795-8	PLATE C	1	PC.
37	212001-8	NEEDLE BEARING 708	1	PC.
38	125320-2	GEAR ASSEMBLY	1	
	D10	INC. 39		
39	212074-1	NEEDLE BEARING 1012	1	PC.
40	253797-2	FLAT WASHER 14	1	PC.
41	232222-6	LEAF SPRING B	1	PC.
42	345479-1	SHOE GUIDE	1	PC.
43	265165-7	TORX SOCKET C.S.HEADSCREW M6X16	1	PC.
44	266041-8	TAPPING SCREW 5X25	4	PC.
45	154812-4	GEAR HOUSING COMPLETE	1	
46	912207-5	COUNTERSUNK HEAD SCREW M5X10	2	PC.
47	951057-3	SPRING PIN 3-12	1	PC.
48	313127-0	JOINT	1	
49	233455-6	COMPRESSION SPRING 7	1	
50	262561-0	SLEEVE 6	1	

51	281218-4	HOOK	1	
52	264002-2	SQUARE NUT M5	2	
53	125321-0	HOOK ASSEMBLY	1	
	D10	INC. 47-51		
54	961052-5	RETAINING RING S-12	1	PC.
55	210102-6	BALL BEARING 6001DDW	1	PC.
56	961016-9	STOP RING E-10	1	PC.
57	911225-0	PAN HEAD SCREW M5X16	2	PC.
58	285726-7	BEARING RETAINER 63	1	
59	241869-5	FAN 55	1	PC.
60	519176-7	ARMATURE ASSY 18V	1	
	D10	INC. 59,61		
61	210062-2	BALL BEARING 607ZZ	1	PC.
62	419333-6	BAFFLE PLATE	1	
63	638107-8	YOKE UNIT	1	PC.
64	419327-1	COVER	1	
65	419330-2	MOTOR HOUSING	1	
66	266292-3	TAPPING SCREW 4X65	2	PC.
67	643941-3	BRUSH HOLDER CAP	2	PC.
68	191976-3	CARBON BRUSH CB-432	1	SET
69	643949-7	BRUSH HOLDER R	1	PC.
70	862359-1	BJR181 NAME PLATE	1	
71	188046-7	HANDLE SET	1	
	D10	INC. 82		
72	643812-4	TERMINAL	1	PC.
73	419336-0	SWITCH LEVER	1	
74	650574-7	SWITCH C3LA-2A-LLM	1	
75	232152-1	LEAF SPRING	1	PC.
76	419334-4	LOCK OFF BUTTON	1	
77	631690-4	POWER SUPPLY CIRCUIT	1	
78	643815-8	BRUSH HOLDER	1	
79	911006-2	PAN HEAD SCREW M3X8	1	PC.
80	689116-0	HEAT SINK	1	PC.
81	266045-0	TAPPING SCREW 4X20	6	PC.
82	188046-7	HANDLE SET	1	
	D10	INC. 71		