



Parts List for D55153 Type 2

Item Number	Part Number	Description	Qty Required
1	5140028-29	BASE PLATE	1
2	5137078-00	PUMP/MOTOR ASSY.	1
3	5140028-07	TANK	1
4	A17037	GRIP	1
5	5130205-00	GAUGE	1
6	629406-00	PRESSURE SWITCH	1
7	5130019-01	SCREW	4
8	5140030-78	CHECK VALVE ASSY	1
9	629409-00	COMPRESSION NUT	1
10	5130046-00	CORD & PLUG	1
11	629407-00	UNLOADER TUBE	1
12	A17038	DRAIN VALVE	2
13	5130628-00	FOOT	4
14	5130030-00	VALVE	1
15	A12446	SELF TAPPING SCREW	4
16	5131722-00	REGULATOR	1
18	629401-00	AFTERCOOLER	1
19	5130023-00	ELBOW	1
22	5130033-00	COLD START VALVE	1
23	5135169-02	NAMEPLATE	1
25	N044990	NIPPLE CLOSE 1/4-18	1
28	627676-00	WARNING LABEL	1
29	626966-00	LABEL	1
30	N000231	LABEL	1
32	5130035-00	NUT	2
33	5131650-00	GAUGE	1
34	5130039-00	SLEEVE	2

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for D55153 Type 2

Item Number	Part Number	Description	Qty Required
35	629408-00	COMPRESSION RING	1
43	438010040063	HEYCO BUSHINGS	1
43	SSW-7367	BUSHING STRAIN RELIE	2
44	450213-00	TERMINAL,FEMALE	2
45	5130458-00	TERMINAL	1
46	5130034-00	SLEEVE	2
47	N018445	WARNING LABEL	2
48	5130059-00	DECAL	1
49	5130054-00	DECAL	1
50	000000-00	No Longer Available	1
51	000000-00	No Longer Available	1
201	5130077-00	BOLT	4
203	5130284-00	HEAD	1
204	5140019-80	FILTER	1
205	5140026-38	HEAD GASKET	1
206	5140016-72	VALVE PLATE	2
207	5140026-39	GASKET	1
208	5140016-73	VALVE BLADE	2
209	5140016-74	VALVE PLATE GASKET	1
210	5140016-95	CYLINDER	1
211	5130105-00	BOLT	2
212	5140026-40	GASKET	1
213	5130084-00	PISTON RING SET	1
214	5130085-00	PISTON	1
215	5130086-00	PIN	1
216	5130087-00	RETAINING RING	2
217	5130102-00	PISTON ASSY.	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for D55153 Type 2

Item Number	Part Number	Description	Qty Required
218	5130088-00	CONNECTING ROD	1
219	5140016-76	CONDENSER	1
220	5140016-77	COVER	1
222	5140016-78	DIPSTICK	1
223	5140016-79	SCREW	4
224	5140026-44	COVER	1
225	5140016-81	O-RING	1
226	5140016-82	SCREW	1
227	5140016-83	COVER,SEAL	1
228	5140040-44	CASE ASSY	1
229	5130101-00	NUT	2
230	5134583-00	CIRCUIT BREAKER	1
231	5140016-86	CRANKSHAFT	1
232	5140016-87	BEARING	1
233	5140016-88	SEAL	1
236	5134652-00	BEARING	1
237	5134707-00	END COVER	1
238	5140016-91	SCREW	2
239	5130107-00	FAN	1
240	5140016-92	HOUSING	1
241	5130097-00	SCREW	2
243	5140026-42	O-RING	1
244	5140026-48	WASHER	2
800	5130702-00	OIL	1
800	5130427-00	OIL	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.