



Parts List for D55154 Type 1

Item Number	Part Number	Description	Qty Required
1	5137078-00	PUMP/MOTOR ASSY.	1
50	5140038-28	TANK	1
51	5140053-05	PRESSURE SWITCH	1
51	5140050-55	PRESSURE SWITCH	1
52	5140038-30	TUBE	1
53	5140038-31	TUBE	1
54	5140038-32	FOOT PAD	1
55	5140038-33	KNOB	2
56	5140038-34	HANDLE	1
57	5140038-35	WHEEL	2
58	5140038-36	WASHER	2
59	5140038-37	PLATE	2
60	5140038-38	SLEEVE	2
61	5140038-39	SLEEVE	2
62	5140038-40	PIN	2
63	5140038-41	CLIP	2
64	5140038-42	STOPPER	2
65	5140038-43	COVER	1
66	5140038-44	PRESSURE GAUGE	2
67	5140050-56	CORDSET	1
67	5140038-45	CORDSET	1
68	5140028-18	LOCKNUT	2
69	629409-00	COMPRESSION NUT	1
70	629408-00	COMPRESSION RING	1
71	5140028-17	COMPRESSION RING	2
72	5140028-19	COMPASS	2
73	5140028-16	ELBOW	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenetwork.com for current parts information.

Parts List for D55154 Type 1

Item Number	Part Number	Description	Qty Required
74	5140038-46	ELBOW	2
75	5140030-62	QUICK COUPLER	2
76	5137078-00	PUMP/MOTOR ASSY.	1
77	5140019-80	FILTER	1
78	5140028-14	SAFETY VALVE	1
79	5140028-59	ELBOW	1
80	5130033-00	COLD START VALVE	1
81	5140030-78	CHECK VALVE ASSY	1
82	5140038-47	AIR PIPE	1
83	5140038-48	HOSE CLAMP	2
84	5140028-60	NUT	12
85	5140030-78	CHECK VALVE ASSY	1
86	5140028-20	NIPPLE	1
87	5140038-49	DRAIN VALVE	1
88	5140038-50	FRONT PANEL	1
89	5140038-51	MANIFOLD	1
90	5140028-27	SCREW	16
91	5140028-28	SCREW,SELF-TAP.	6
92	5140028-29	BASE PLATE	1
93	5140028-30	GROMMET	1
94	5140038-53	CABLE CLAMP	1
95	A18358	NAMEPLATE	1
96	5140031-81	WARNING LABEL	1
97	A18336	WARNING LABEL	1
201	5130077-00	BOLT	4
203	5140016-71	CYLINDER HEAD	1
204	5140019-80	FILTER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenetwork.com for current parts information.

Parts List for D55154 Type 1

Item Number	Part Number	Description	Qty Required
205	5130078-00	GASKET	1
206	5140016-72	VALVE PLATE	1
207	5140026-39	GASKET	1
208	5140016-73	VALVE BLADE	2
209	5140016-74	VALVE PLATE GASKET	1
210	5140016-95	CYLINDER	1
211	5130105-00	BOLT	2
212	5140016-75	SEAL	1
213	5130084-00	PISTON RING SET	1
214	5130085-00	PISTON	1
215	5130086-00	PIN	1
216	5130087-00	RETAINING RING	2
217	5130102-00	PISTON ASSY.	1
218	5130088-00	CONNECTING ROD	1
219	5140016-76	CONDENSER	1
220	5140016-77	COVER	1
222	5140016-78	DIPSTICK	1
223	5140016-79	SCREW	4
224	5140016-80	COVER,MOTOR	1
225	5140016-81	O-RING	1
226	5140016-82	SCREW	1
227	5140016-83	COVER,SEAL	1
228	5140040-44	CASE ASSY	1
229	5130101-00	NUT	2
230	5134583-00	CIRCUIT BREAKER	1
231	5140016-86	CRANKSHAFT	1
232	5140016-87	BEARING	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for D55154 Type 1

Item Number	Part Number	Description	Qty Required
233	5140016-88	SEAL	1
234	000000-00	No Longer Available	1
235	000000-00	No Longer Available	1
236	5134652-00	BEARING	1
237	5134707-00	END COVER	1
238	5140016-91	SCREW	2
239	5130107-00	FAN	1
240	5140016-92	HOUSING	1
241	5130097-00	SCREW	2
243	5140016-94	SEAL KIT	1
800	5130702-00	OIL	3

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.