



## Parts List for DC020 Type 1

Item Number	Part Number	Description	Qty Required
1	5140058-13	WASHER	3
2	5140058-12	REFLECTOR ASSY	1
3	5140058-14	SCREW	3
5	5140046-53	LENS	1
6	5140058-15	SPRING & COVER	1
7	5140058-16	SPRING & COVER	1
8	5140058-02	SIDE RAIL	1
9	5140058-01	SIDE RAIL	1
11	5140046-71	RECEPTACLE	2
12	5140058-03	SUPPORT ARM	1
13	5140058-04	HANDLE ASSY.	1
14	5140058-17	GUARD	1
15	5140058-05	TERMINAL BOARD	1
16	5140061-41	CIRCUIT BOARD	1
17	5140058-06	SUPPORT	1
18	5140058-07	SOCKET	1
19	5140058-08	LABEL SET	1
20	5140046-88	SCREW	1
21	5140058-09	POWER SWITCH	1
22	5140058-10	SCREW	1
23	5140058-11	POWER CORD	1
24	5140058-18	CORD CLIP	1
856	651010-00	FLUORESCENT BULB	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenetwork.com](http://www.dewaltservicenetwork.com) for current parts information.