



Parts List for DC490KA Type 1

Item Number	Part Number	Description	Qty Required
1	623778-00	CLAMSHELL SET	1
2	625598-00	WARNING LABEL	1
3	625912-00	WARNING LABEL	1
4	099056-06	WRENCH	1
5	682211-00	SCREW,TORX	1
6	623775-00	NAMEPLATE	1
7	395657-00	ID LABEL	1
8	330019-04	SCREW,PLASTITE	8
9	388822-00SV	HOUSING-BEARING	1
10	091975-00	WASHER	1
11	330019-39	SCREW	4
12	388821-00SV	TRANSMISSION	1
13	098091-10	SCREW	4
14	152482-00	SEAL,FOAM	1
15	606004-10SV	MOTOR & PINION	1
16	607100-00	LOCK-OFF BUTTON	1
17	152274-15	SWITCH,VSR	1
18	626176-00	LEADWIRE,BLACK	1
19	626177-00	LEADWIRE,RED	1
20	603754-01	BRUSH BOX	2
21	448393-01	ECCENTRIC	1
28	91971-00	HOUSING	1
37	91968-00	SPACER	2
38	91969-00	LEFT KNIFE	1
42	91970-00	BLADE	1
45	679889-00	SCREW,SPECIAL	3
46	91967-00	RIGHT KNIFE	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for DC490KA Type 1

Item Number	Part Number	Description	Qty Required
47	91966-00	INSERT	3
800	286436-00	GREASE	1
861	625469-00	KIT BOX	1
866	DC9096	BATTERY PACK	2
867	645221-00	BATTERY CAP	2
871	388683-12	1 HOUR CHARGER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.