



Parts List for DC750-BR Type 2

Item Number	Part Number	Description	Qty Required
1	649284-01	CLAMSHELL SET	1
2	389080-00	BUTTON(FWD/REV)	1
3	389081-01	TERMINAL BOARD	1
4	391092-00SV	LEAD-RED	1
5	391091-00SV	LEAD-BLACK	1
6	682211-00	SCREW,TORX	1
7	391996-00	SHIFTER ASSY.	1
8	631445-01SV	MOTOR & PINION	1
9	389103-00	WASHER	1
11	330075-87	CHUCK	1
12	638563-01	TRANSMISSION ASSY.	1
13	149518-01	SCREW	1
14	152274-28	VSR SWITCH (DC)	1
15	395657-00	ID LABEL	1
16	148354-03	BIT CLIP	1
17	607918-41	SCREWDRIVER BIT	1
20	562160-01	SCREW	2
21	649714-00	NAMEPLATE	1
22	389083-00	PLATE	1
866	N084519	BATTERY PACK	2
871	388683-15	CHARGER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.