



## Parts List for DW321K Type 3

Item Number	Part Number	Description	Qty Required
101	387658-00	ARMATURE	1
102	402051-01	FIELD	1
103	402182-01	SWITCH	1
104	930897-00	BRUSH	2
105	330072-98	CORD/8FT/18-2SJ	1
111	949876-21	WASHER	1
112	402154-00	SPACER	1
113	402105-00	PIN	1
114	000000-00	No Longer Available	1
115	402161-00SV	ECCENTRIC	1
116	932302-00	WASHER	3
117	949728-04	CIRCLIP	2
118	402118-00	YOKE	1
119	402155-00	BUSHING	1
120	389235-00	SCREW	2
121	399146-00	CLAMP	1
122	000000-00	No Longer Available	2
123	949876-20	WASHER	1
124	949400-00	FELT	1
126	402177-00	SEAL	1
130	402097-00	CAM	1
131	402116-00	GUARD	2
133	330041-08	PIN ROLLER	1
134	389235-00	SCREW	4
139	330041-29	PIN	1
140	389652-00	PLATE,SOLE	1
141	402151-00	MOUNT	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.

## Parts List for DW321K Type 3

Item Number	Part Number	Description	Qty Required
143	000000-00	No Longer Available	1
144	402150-00	PLATE	1
145	860310-00	NUT	1
146	949701-13	SCREW	1
148	388968-01	BAFFLE	1
149	402652-00	PLATE	1
150	615797-00	LEVER	1
152	330003-03	BEARING,BALL	1
153	176838-00	FAN	1
154	402059-01	CASE,FIELD	1
155	330003-56	BALL BEARING	1
156	930029-00	COVER,BRG	1
157	402186-01	CAP,END	1
158	402111-00	SPRING	1
159	402098-00	COUNTERWEIGHT	1
160	402112-00	GASKET	1
161	604737-00	GEAR	1
162	000000-00	No Longer Available	1
163	330004-06	BEARING,NEEDLE	2
164	949400-03	FELT	1
165	402125-00	COVER	1
166	330065-07	SCREW	6
167	935616-00	CLAMP,CORD	1
168	000000-00	No Longer Available	1
169	940988-64	LEAD	1
170	330005-01	PROTECTOR,CORD	1
171	949880-05	BRUSH HOLDER	2

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.

### Parts List for DW321K Type 3

Item Number	Part Number	Description	Qty Required
172	930090-00	SPRING	2
173	330019-02	SCREW,PLASTITE	2
174	402158-03SV	CLUTCH ASSEMBLY	1
175	326467-00	DETENT	2
176	941374-01	PLUG,RUBBER	1
177	603338-00	GEAR CASE	1
179	930079-01	SCREW	2
180	402137-00SV	KNOB	1
181	000000-00	No Longer Available	1
182	330045-09	SCREW	2
183	330045-06	SCREW	2
184	000000-00	No Longer Available	1
185	930082-01	SCREW	2
186	000000-00	No Longer Available	1
187	000000-00	No Longer Available	1
190	000000-00	No Longer Available	1
192	329982-00	SOLE PLATE	1
193	607973-00	BUSHING	1
194	388577-00	SUPPORT ASM	1
195	388911-00	SHOE SUPPORT	1
200	099389-06	WASHER	1
201	948603-00SV	SPINDLE ASSY	1
211	330065-06	SCREW	2
212	609364-00	SPACER	1
216	000000-00	No Longer Available	1
217	603215-00	SCREW	2
220	000000-00	No Longer Available	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.

### Parts List for DW321K Type 3

Item Number	Part Number	Description	Qty Required
800	761995-01	GREASE, 6 OZ.	1
800	283484-01	GREASE,32 OZ.	1
816	946194-00	LABEL	1
821	609016-00	NAMEPLATE	1
856	000000-00	No Longer Available	1
856	DW3753-5	JIGSAW BLADE (5PK)	1
861	393455-00	KIT BOX	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.