

Parts List for DW323K Type 1

Item Number	Part Number	Description	Qty Required
101	000000-00	No Longer Available	1
102	402051-01	FIELD	1
103	000000-00	No Longer Available	1
104	930897-00	BRUSH	2
105	330072-98	CORD/8FT/18-2SJ	1
106	860322-01	CIRCLIP	1
107	606410-00	WASHER	2
108	402960-00SV	CLUTCH	1
109	402110-00	SPRING	1
111	949876-21	WASHER	1
112	402154-00	SPACER	1
113	402105-00	PIN	1
114	000000-00	No Longer Available	1
115	402161-00SV	ECCENTRIC	1
116	932302-00	WASHER	3
117	949728-04	CIRCLIP	2
118	402118-00	YOKE	1
119	402155-00	BUSHING	1
120	860205-04	SCREW	4
121	399146-00	CLAMP	1
122	000000-00	No Longer Available	2
123	949876-20	WASHER	1
124	949400-00	FELT	1
126	402177-00	SEAL	1
129	389599-00	SCREEN	1
130	402097-00	CAM	1
131	402116-00	GUARD	2

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for DW323K Type 1

Item Number	Part Number	Description	Qty Required
133	329923-49	PEND.REPAIR KIT	1
134	327136-00	SCREW	4
138	949728-03	CIRCLIP	2
139	330041-29	PIN	1
140	000000-00	No Longer Available	1
141	402151-00	MOUNT	1
143	000000-00	No Longer Available	1
144	402150-00	PLATE	1
145	330003-03	BEARING,BALL	1
146	860310-00	NUT	1
147	949701-13	SCREW	1
149	000000-00	No Longer Available	1
150	402652-00	PLATE	1
152	615797-00	LEVER	1
153	493248-00	LEVER	1
154	402433-01	BUTTON	1
155	402432-00	LEVER	1
156	402429-01	CASE,FIELD	1
157	943051-00	SPRING	1
158	330003-02	BEARING,BALL	1
159	930275-00	COVER,BEARING	1
160	000000-00	No Longer Available	1
161	402111-00	SPRING	1
162	000000-00	No Longer Available	2
163	402098-00	COUNTERWEIGHT	1
164	402112-00	GASKET	1
165	000000-00	No Longer Available	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for DW323K Type 1

Item Number	Part Number	Description	Qty Required
166	611147-00	GEAR & BEARING	2
167	949400-03	FELT	1
168	402125-00	COVER	1
169	000000-00	No Longer Available	1
170	949880-05	BRUSH HOLDER	2
171	930090-00	SPRING	2
172	330065-07	SCREW	3
173	935616-00	CLAMP,CORD	1
174	330005-01	PROTECTOR,CORD	1
175	931469-02	SCREW	4
176	000000-00	No Longer Available	1
177	326467-00	DETENT	2
178	000000-00	No Longer Available	1
179	402962-00	KNOB ASSY	1
180	930079-01	SCREW	2
181	402133-00	KNOB	1
182	402131-00	KNOB	1
183	000000-00	No Longer Available	1
184	000000-00	No Longer Available	2
185	000000-00	No Longer Available	1
186	930082-01	SCREW	2
187	402160-01	LEVER	1
188	000000-00	No Longer Available	1
191	402113-01	LEVER	1
192	402140-00	DEVICE,ANTI.SPL	1
193	000000-00	No Longer Available	1
194	607973-00	BUSHING	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for DW323K Type 1

Item Number	Part Number	Description	Qty Required
195	388577-00	SUPPORT ASM	1
196	000000-00	No Longer Available	1
198	000000-00	No Longer Available	2
199	402959-00	INSERT	1
200	327012-00	WASHER,SPRING	1
201	948603-00SV	SPINDLE ASSY	1
816	946194-00	LABEL	1
821	000000-00	No Longer Available	1
861	393455-00	KIT BOX	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.