



Parts List for DW432 Type 1

Item Number	Part Number	Description	Qty Required
1	398028-00SV	GEAR CASE	1
2	330045-06	SCREW	17
3	398097-00SV	SHAFT ASSEMBLY	1
4	398050-00	LEVER	1
5	398074-00	TENSION SPRING	1
6	398064-00	BUSHING	1
7	098023-25	SCREW	1
8	397893-00	STOP NUT	1
9	330016-02	WASHER,PLAIN	1
10	393745-00	PLATEN	1
11	393758-00	O-RING	1
12	398094-00	NUT	1
13	398080-00SV	STEEL PLATE	1
14	398049-00	CLAMP	1
15	153637-04	SCREW	3
16	398065-00	COVER	1
17	398076-00SV	ARMATURE & BRG.	1
19	402051-03SV	FIELD	1
20	393742-00	FIELD CASE	1
21	398045-01	BRUSH	2
22	393747-00	BAFFLE	1
23	949638-02	PLUG,RUBBER	4
24	398105-00	COLLAR	1
25	398108-00	BRUSH HOLDER	2
26	176951-00	SCREW	4
27	072412-00	PLUG	2
28	398036-00	FRONT HANDLE	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for DW432 Type 1

Item Number	Part Number	Description	Qty Required
29	615509-00	ROLLER	2
30	330019-14	SCREW	9
31	398098-00	SCREW	1
32	398117-01	HANDLE & COVER	1
33	330005-01	PROTECTOR,CORD	1
34	36480-98	CORD/10FT./18-3	1
35	380414-00	CLAMP,CORD	1
36	N033990	CONTROL MODULE	1
37	330045-07	SCREW M4X20 T20	6
38	619242-00	SWITCH	1
40	609468-00	THERMAL PAD	1
41	619714-01	WIRE HARNESS	1
41	612653-01	WIRE HARNESS	1
42	398078-00	LEAD	1
43	398078-01	LEAD	1
44	398100-00	TERMINAL BLOCK	1
45	330015-01	NUT,HEX	2
46	150036-01	SCREW	1
47	393741-00	DRIVE PULLEY	1
48	330015-04	NUT,HEX	1
49	398029-00	DRIVE BELT	1
50	398030-00	DRIVEN PULLEY	1
51	330015-09	NUT	1
52	398096-00SV	SHAFT ASSEMBLY	1
53	393753-00	PLANET GEAR	3
54	393755-00	RING GEAR	1
55	N174784	SHAFT/ROLLER KIT	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for DW432 Type 1

Item Number	Part Number	Description	Qty Required
56	393759-00	PLATE	1
57	N174784	SHAFT/ROLLER KIT	1
58	330003-63	BALL BEARING	2
59	385244-00	RING,RETAINING	2
60	640257-00	YOKE ASSY	1
61	398068-00	SPACER	1
62	614545-00	ROLLER	1
63	398039-00	SHAFT	1
64	398101-04SV	SHROUD	1
65	606899-00	NUT	1
66	393746-00	BAFFLE	1
67	393743-00SV	FAN	1
69	330045-13	SCREW,TAPTITE	1
70	393749-01	O-RING	1
71	398027-01	FRAME	1
72	613099-00	SCREW	2
73	398083-00	BAFFLE	1
74	398079-00	CLIP	1
75	330015-02	NUT,HEX	2
76	398070-00	TRACKING KNOB	1
77	398071-00SV	BELT COVER	1
80	398075-04	NAME PLATE	1
83	617084-00	DOWEL PIN	1
85	636658-00	BAFFLE	1
104	398082-00	HOLDER	1
105	398072-00	BAG FRAME	1
106	617085-00	CLIP	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for DW432 Type 1

Item Number	Part Number	Description	Qty Required
120	330003-60	BEARING	2
122	88667-04	TERMINAL	1
125	330003-60	BEARING	4
126	617115-00	WARNING LABEL	1
127	398115-00	LABEL	1
128	612953-02	WARNING LABEL	1
800	761995-01	GREASE, 6 OZ.	1
800	283484-01	GREASE,32 OZ.	1
836	233804-30	WRENCH	1
856	DW4050	VACUUM ADAPTER	1
856	340608-01	SANDING BELT	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.