



Parts List for DW933K Type 1

Item Number	Part Number	Description	Qty Required
101	606047-00SV	DC MOTOR ASM	1
103	152274-19SV	SWITCH- V.S.R.	1
104	389025-01SV	BRUSH PAIR KIT	1
105	099389-06	WASHER	1
106	860322-01	CIRCLIP	1
107	606410-00	WASHER	1
108	402960-00SV	CLUTCH	1
109	402110-00	SPRING	1
110	388957-00	WASHER	1
111	949876-21	WASHER	1
112	402154-00	SPACER	1
113	402105-00	PIN	1
114	000000-00	No Longer Available	1
115	402161-00SV	ECCENTRIC	1
116	932302-00	WASHER	3
117	949728-04	CIRCLIP	2
118	402118-00	YOKE	1
119	402155-00	BUSHING	1
120	603215-00	SCREW	4
121	399146-00	CLAMP	1
122	000000-00	No Longer Available	2
123	949876-20	WASHER	1
124	949400-00	FELT	1
126	402177-00	SEAL	1
127	948603-00SV	SPINDLE ASSY	1
129	389599-00	SCREEN	1
130	402097-00	CAM	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for DW933K Type 1

Item Number	Part Number	Description	Qty Required
131	402116-00	GUARD	2
133	330041-08	PIN ROLLER	1
134	327136-00	SCREW	4
139	330041-29	PIN	1
141	402151-00	MOUNT	1
143	860310-00	NUT	1
144	949701-13	SCREW	1
145	402652-00	PLATE	1
146	329635-00	ADAPTER PLATE	1
154	402111-00	SPRING	1
155	402098-00	COUNTERWEIGHT	1
156	402112-00	GASKET	1
157	611147-00	GEAR & BEARING	1
160	330065-07	SCREW	8
162	389025-01SV	BRUSH PAIR KIT	1
163	389025-01SV	BRUSH PAIR KIT	1
165	611147-00	GEAR & BEARING	2
165	330004-06	BEARING,NEEDLE	2
171	402158-03SV	CLUTCH ASSEMBLY	1
172	387850-01SV	GEAR CASE	1
175	402137-00SV	KNOB	1
176	000000-00	No Longer Available	1
177	330045-09	SCREW	2
178	330045-45	SCREW	2
179	000000-00	No Longer Available	1
180	330045-15	SCREW,M5X20	6
181	000000-00	No Longer Available	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for DW933K Type 1

Item Number	Part Number	Description	Qty Required
182	000000-00	No Longer Available	1
185	000000-00	No Longer Available	1
186	941374-01	PLUG,RUBBER	1
187	326467-00	DETENT	2
188	402140-00	DEVICE,ANTI.SPL	1
190	329982-00	SOLE PLATE	1
193	388577-00	SUPPORT ASM	1
195	389003-00	SHOE SUPPORT	1
197	402150-00	PLATE	1
198	615797-00	LEVER	1
199	493248-00	LEVER	1
203	000000-00	No Longer Available	1
212	609364-00	SPACER	1
222	607100-00	LOCK-OFF BUTTON	1
223	389322-00	SCREW	4
224	329812-00SV	FAN ASM	1
230	330003-59	BALL BEARING	1
231	330003-04	BEARING,BALL	1
232	382816-00	LABEL,WARNING	1
816	616567-00	NAMEPLATE	1
817	329637-00	ID LABEL	1
856	1004501-00	RIP FENCE	1
856	DW3760-5	JIGSAW BLADE (5PK)	1
857	DW3753-5	JIGSAW BLADE (5PK)	1
858	000000-00	No Longer Available	1
861	N179861	KIT BOX	1
866	DC9096	BATTERY PACK	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for DW933K Type 1

Item Number	Part Number	Description	Qty Required
867	645221-00	BATTERY CAP	2
871	388683-12	1 HOUR CHARGER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.